

| Model                                          | Flex Hoe 400                              | Flex Hoe 700                           |
|------------------------------------------------|-------------------------------------------|----------------------------------------|
| Seeding Method                                 | Min-Till / Conventional Till hoe          | Min-Till / Conventional Till hoe       |
| Row Spacings, in (mm)                          | 7.2, 10, 12 (183, 254, 305)               | 7.5, 10, 12 (191, 254, 305)            |
| Seed Supply, Air Cart or Integral Tank, bu (L) | Air Cart                                  | Air Cart                               |
| Frame Sections & Transport Folding Method      | 3 & 5 section vertical fold               | 5-section, horizontal rear fold        |
| Working Width, Minimum, ft-in (m)              | 27' (8.2)                                 | 60' (18.3)                             |
| Working Width, Maximum, ft-in (m)              | 57' (17.4)                                | 70' (21.3)                             |
| Number of Furrows, Minimum                     | 28                                        | 60                                     |
| Number of Furrows, Maximum                     | 85                                        | 96                                     |
| Basic Weight, Maximum, lb (kg)                 | 33,700 (15286)                            | 36,500 (16516)                         |
| Opener Type                                    | Conventional single pivot spring trip hoe | Conventional C-shank std; Edge-on opt. |
| Depth Gauging System                           | Fixed to frame                            | Fixed to frame                         |
| Trip Load, lb (kg)                             | 350 or 550 (159 or 250)                   | 350 or 550 (159 or 250)                |
| Fertilizer Delivery                            | Single/double shoot                       | Single/double shoot                    |
| Press Wheels Mounted on Opener or to Frame     | Frame-mounted                             | Frame-mounted                          |
| Press Wheel Description                        | Steel Wheel or Semi-pneumatic Tire        | Steel Wheel or Semi-pneumatic Tire     |