



2019





# Adult Occupant



88%





85%

Vulnerable Road Users



68%



Safety Assist

74%

### **SPECIFICATION**

Tested Model	SsangYong Korando 1.6 diesel, LHD
Body Type	- 5 door SUV
Year Of Publication	2019
Kerb Weight	1728kg
VIN From Which Rating Applies	- all Korandos
Class	Small Family Car

# **SAFETY EQUIPMENT**

	Driver	Passenger	Rear
FRONTAL CRASH PROTECTION			
Frontal airbag	•	•	×
Belt pretensioner	•	•	•
Belt loadlimiter	•	•	•
Knee airbag	0	×	×
SIDE CRASH PROTECTION			
Side head airbag	•	•	•
Side chest airbag	•	•	×
Side pelvis airbag	•	•	×



# **SAFETY EQUIPMENT (NEXT)**

	Driver	Passenger	Rear
CHILD PROTECTION			
Isofix	_	×	•
Integrated CRS	_	×	×
Airbag cut-off switch	_	•	_
SAFETY ASSIST			
Seat Belt Reminder	•	•	•

OTHER SYSTEMS	
Active Bonnet (Hood)	×
AEB Pedestrian	•
AEB Cyclist	•
AEB City	•
AEB Inter-Urban	•
Speed Assistance System	•
Lane Assist System	•

Note: Other equipment may be available on the vehicle but was not considered in the test year				
	Note: Other equipment r	nay be available on the	vehicle but was not	concidered in the test year

	Fitted to the vehicle as standard	Fitted to the vehicle as part of the safety pack
1	I ILLEG LO LITE VETILLE OS SLOTIGOTO	I I ILLEG LO LITE VETILLE OS DOTL OF LITE SOFELV DOCK

O Not fitted to the test vehicle but available as option or as part of the safety pack X Not available — Not applicable







Total 33.8 Pts / 88%

















Total 33.8 Pts / 88%



**AEB City** 

4 / 4 Pts







Version 200819





Total 33.8 Pts / 88%

#### Comments

The passenger compartment of the Korando remained stable in the frontal offset test. Dummy readings indicated good protection of the knees and femurs for both driver and passenger. SsangYong showed that a similar level of protection would be provided to occupants of different sizes and to those sitting in different positions. In the full-width rigid barrier test, protection of the driver dummy was good or adequate. For the rear dummy, readings indicated a drop in the iliac force, indicating that the pelvis had slipped underneath the lap section of the seatbelt, a phenomenon known as 'submarining'. Although dummy readings did not indicate a high risk of injury, the car was penalised and protection of the pelvis rated as poor. in the side barrier test, protection of all critical body areas was good and the Korando scored maximum points. In the more severe side pole impact, dummy readings of rib deflection indicated marginal protection of the chest, while that of other critical body areas was good. Tests on the front seats and head restraints demonstrated good protection against whiplash injuries in the event of a rear-end collision. A geometric assessment of the rear seats indicated marginal whiplash protection. The standard-fit autonomous emergency braking (AEB) system scored maximum points in tests of its functionality at the low speeds at which many whiplash injuries occur, with car-to-car collisions avoided in all test scenarios.



Total 41.8 Pts / 85%



### Crash Test Performance based on 6 & 10 year old children

22.8 / 24 Pts





Restraint for 6 year old child: *Britax Römer KIDFIX II XP SICT* Restraint for 10 year old child: *Booster Cushion* 

Safety Features 7 / 13 Pts

	Front Passenger	2nd row outboard	2nd row center
Isofix	×	•	×
i-Size	×	•	×
Integrated CRS	×	×	×

Fitted to test car as standard

O Not on test car but available as option

🗶 Not available

#### **CRS Installation Check**

12 / 12 Pts

Install without problem
Install with care
Safety critical problem
Installation not allowed

#### i-Size CRS













### ISOFIX CRS









### Universal Belted CRS











Total 41.8 Pts / 85%

		Seat Position		
	Front		2nd row	
	PASSENGER	LEFT	CENTER	RIGHT
Maxi Cosi 2way Pearl & 2wayFix (rearward) (iSize)		•	0	•
Maxi Cosi 2way Pearl & 2wayFix (forward) (iSize)		•		•
BeSafe iZi Kid X2 i-Size (iSize)		•	0	•
BeSafe iZi Flex FIT i-Size (iSize)		•		•
Maxi Cosi Cabriofix & FamilyFix (ISOFIX)		•		•
BeSafe iZi Kid X4 ISOfix (ISOFIX)		•		•
Britax Römer Duo Plus (ISOFIX)		•	0	•
Britax Römer KidFix XP (ISOFIX)		•		•
Maxi Cosi Cabriofix (Belt)	•	•	•	•
Maxi Cosi Cabriofix & EasyBase2 (Belt)	•	•	×	•
Britax Römer King II LS (Belt)	•	•	•	•
Britax Römer KidFix XP (Belt)	•	•	•	•

Install without problem

Install with care

Safety critical problem

★ Installation not allowed

#### Comments

In the frontal offset test, protection of the six-year dummy was good for all critical body areas. For the ten-year-old, dummy readings of neck tension indicated marginal protection for this body region, but protection elsewhere was good. In the side barrier test, protection of all critical parts of the body was good for both child dummies. The front passenger airbag can be disabled to allow a rearward-facing child restraint to be used in that seating position. Clear information is provided to the driver regarding the status of the airbag and the system was rewarded. All restraint types for which the Korando is designed could be properly installed and accommodated in the car.





Total 33.1 Pts / 68%

GOOD	ADEQUATE	MARGINAL	WEAK	POOR	
Pedestrian				26 /	36 Pts
		F	lead Impact	17.1 Pt:	S
		F	Pelvis Impact	2.9 Pt:	5
		L	eg Impact	6 Pts	5

7 / 12 Pts
Autonomous Emergency Braking
Auto-Brake with Forward Collision Warning
8 km/h

#### Comments

The protection provided to the head of a struck pedestrian was good or adequate over most of the bonnet surface, with poor results recorded at the base of the windscreen and on the stiff windscreen pillars. Protection of pedestrians' legs was good at all test locations but protection of the pelvis was mixed. The AEB system of the Korando can detect vulnerable road users like pedestrians and cyclists, as well as other vehicles. In tests of its response to pedestrians, the system performed adequately. The system's reaction to cyclists was rated as marginal.



Total 33.1 Pts / 68%


### **AEB** Pedestrian

Day time

Adult crossing the road



Child running from behind parked vehicles




Adult along the roadside




Night time

Adult crossing the road




Adult along the roadside



# AEB Cyclist


Cyclist crossing



Cyclist along the roadside







Lane Support	3.3 / 4 Pts

System Name	Lane Support System
Туре	ELK + LKA (including LDW)
Operational From	60 km/h
PERFORMANCE	
Emergency Lane Keeping	GOOD
Lane Keep Assist	GOOD
Human Machine Interface	ADEQUATE

Pass

Fail

— Not available





Total 9.7 Pts / 74%

#### **AEB Inter-Urban**

2.4 / 3 Pts


System Name	Autonomous Emergency Braking
Туре	Autonomous Emergency Braking and Forward Collision Warning
Operational From	8 km/h

#### Comments

The AEB system performed well in tests of its response to other vehicles at highway speeds, with collisions avoided in almost all test scenarios. A seatbelt reminder system is standard for the front and rear seats. A camera-based speed limit recognition system presents the information the driver, allowing the speed limiter to be set appropriately. The lane support system helps to prevent inadvertent drifting out of lane and also intervenes more aggressively in certain critical situations.

### Autobrake function only


Approaching a slower moving car




Approaching a slower moving car



Approaching a slower moving car



Approaching a braking car







Total 9.7 Pts / 74%

### Driver reacts to warning


Approaching a stationary car




Approaching a stationary car




Approaching a slower moving car




Approaching a braking car




Approaching a stationary car



Approaching a slower moving car



Approaching a slower moving car





# **RATING VALIDITY**

# Variants of Model Range

Body Type	Engine & Transmission	Drivetrain	Rating Applies	
			LHD	RHD
			✓	
5 door SUV	1.6 diesel	4 x 2		~
5 door	1.6 diesel*	4 x 4	✓	✓
SUV				
5 door SUV	1.5 petrol	4 x 2	✓	~
5 door SUV	1.5 petrol	4 x 4	✓	✓

<sup>\*</sup> Tested variant

### Annual Reviews and Facelifts

Date	Event	Outcome	
September 2019	Rating Published	2019 * * * * *	✓